

A743/A744 Addendum Sheet

Solution

Cushcraft A743/A744 Addendum Sheet

Changes to the manual:

Figure B: Refer to Figure E as necessary.

Figure C: Assembly can be confusing. Start with TC. Insert TC taper into FA, with the slotted end toward TC. Insert FA into FB slotted end and tighten with 411 clamp. Insert FB into FC and tighten with 411. Install clamp 88 over FC. Insert TK into FC and tighten with 411 clamp.

Figure E: Refer to Figure B as necessary.

Article details

Article ID: 234  
Company: [Cushcraft](#)  
Date added: 2018-12-17 12:18:59  
Views: 163